



# QR Code Scanner Connection Sheet

*Note: Each step must be scanned in order.*

## **Enable** **Bluetooth** Scanning

Step 1



Step 2




Step 3



## **Enable USB** **Dongle** Connection


Step 1



Step 2




Step 3



## **Enable USB** **Wired** Connection


Step 1



Step 2



Step 3



# QR Code Scanner

## Advanced Setup



### Battery Life



Scan this code to see the battery life of your scanner. The number will display anywhere you have selected a text box input.

### Continuous Scanning



If using continuous scanning, you will want to also select the "never" power off setting and make sure the scanner is charging via USB

### Automatic Power Off Settings



**5 Minutes**



**30 Minutes**



**Never**

### Manual Scanning



Switch your scanner to manually scan barcodes after each trigger pull

### Bluetooth Device Setup

iOS:

1. Settings
2. Bluetooth
3. **Flip over to front page** and scan bluetooth codes
4. Select **Barcode Scanner HID**
5. Listen for paired complete beep
6. On screen keyboard should disappear (Double pull scanner trigger to activate/deactivate on screen keyboard)

Android:

1. Settings
2. Connected devices
3. Flip to front side and scan bluetooth codes
4. Select **Barcode Scanner HID**
5. Listen for paired complete beep

*Pairing issue? Hold down trigger for 8 seconds to force Bluetooth pairing. Keep holding until the scanner beeps.*